


Science On a Sphere[®]



Users Guide & Training Manual

Last Updated July 2009

Science On a Sphere® Training Manual

Table of Contents

	<u>Page</u>
Overview of Training	1
Session 1. Projector Alignment	4
Session 2. Operation and System Administration	7
Session 3. Overview and Basic System Use	10
Session 4. Presenter Training and Dataset Overview	21
Session 5. Content Creation	22
Appendix A: Helpful Links	29

Overview of Training:

During the setup week for the sphere, NOAA provides Science On a Sphere® system training. SOS system training consists of five separate sessions. There is some overlap between each of the sessions. Each session lasts anywhere from one to two hours.

The five sessions are:

- **Projector Alignment**
- **Operation and Systems Administration**
- **Overview and Basic System Use**
- **Presenter Training and Dataset Overview**
- **Content Creation***

**Note that Overview and Basic System Use is a prerequisite to the session on Content Creation.*

All sessions are taught using the actual sphere system (limited hands-on), so the classes cannot be taught in parallel. Class sizes are variable depending on the interest and usually start by the third day of the setup and wrap up by the end of the fourth day.

Projector Alignment

Projector alignment is usually the first session given because it corresponds to the final stages of the sphere installation. Once the sphere is installed and aligned, the other sessions can begin. Projector alignment training usually occurs during the first two days of setup. Typically, the site personnel who are responsible for projector alignment are also involved with the SOS setup. Alignment training usually happens in the afternoon of day two of the SOS setup and is one and a half to two hours in length.

What is projector alignment training? The SOS system uses four projectors to display data onto the surface of the sphere. The projectors are positioned around the sphere, 90 degrees apart from each other with respect to the center of the sphere. Each projector is responsible for its quadrant of the sphere. Light from adjacent projectors overlaps and makes an edge. These edges need to align very closely to achieve a single unified, global sphere image. This edge is also called the blending area. We call the process of creating a seamless edge blend: projector alignment. The instructor will lead a group through the steps required to perform the projector alignment.

Operation and Systems Administration

This session is intended for the Systems Administrators or IT professionals who will be responsible for maintaining the software and hardware for the SOS system. These individuals will be the primary point of contact for system issues, questions, and problem

resolution. The operations and systems administration training typically occurs on day three and is one to two hours in length.

In this session, we cover a basic system overview as well as a description of the computer components. We go into a detailed discussion of how the pieces fit together and interact. We allocate plenty of time for questions and answers.

Overview and Basic System Use

This session is useful for individuals who will use the system on a daily basis. It is ideal for individuals who are responsible for bringing up the system in the morning and shutting down the system at night. It is also important for people who will be docents with the sphere to attend this training session. Overview and Basic System Use Training typically occurs on day four and is usually one to one and a half hours in length. *This session is a prerequisite for the Content Creation training session.*

In addition to the basic functionality of the system, we will cover how content is organized, how to use the system to display data, how to create new play lists and edit old ones, how to use the remote control, and how to give presentations. Also, during this session the trainer will provide a broad overview of the scientific data sets that are available on the system.

Presenter Training and Dataset Overview

This session covers much of the same information that is presented in the Overview and Basic System Use session. The level of detail, however, is not as in depth, making this appropriate for presenters and docents. In order to target the audience of presenters and docents, this session involves a demonstration of Science On a Sphere given by a NOAA trainer. The demonstration lasts about 40 minutes and includes many datasets from the SOS catalog. The goal of this session is to show museum staff how to use SOS as a presentation tool for audiences (field trips, scheduled presentations, etc). This is also a good time for any museum staff interested in the new exhibit to see it on display.

Also during this session, the NOAA trainer will give an educational overview of the diverse set of SOS datasets that come preloaded on Science On a Sphere ranging from Earth Science data of the oceans to the planets of the solar system. The features of the online dataset catalog will be described so that museum docents will know what data is available to them.

Content Creation

The Content Creation training session is intended for individuals who will create content for the sphere and for people who will work with others to create sphere content. It is also a useful session for people that will be docents with the sphere. The Content Creation training session occurs after the Overview and Basic System Use session on day four and is one and a half to two hours in length.

During this session, the instructor will go into greater detail on the data organization, preferred file formats and how the system interacts with data. Also, all of the options and special features in the playlists will be covered. There will be discussion on how to best go about integrating new content onto the sphere. The instructor will also show the students the steps required to get their own content (both still images and time series) onto the sphere. Individuals are encouraged to bring sample content to try out (NOTE: please review the on-line [FAQ](#) on data formats and the [Content Creation](#) page first!)

Session 1

Projector Alignment

In order to optimize the appearance of Science On a Sphere, it is important to have the sphere properly aligned. Because of this, it is suggested that more than one person at the site learns how to align the sphere.

How to Align the Sphere


To align the sphere, turn on the system as if you were going to do a demo. All of the computers and projectors need to be on. Open the SOS Stream GUI. Open the Wiimote software and make sure that the remote is connected. If it's not connected, simultaneously press "1" and "2" on the remote to connect it. Once the remote is connected, select the Alignment tab in the Wiimote window and press "Start Alignment." You will need the nunchuk attachment for the Wii remote when aligning the sphere.

There are two main modes for aligning the sphere, "Projector Alignment" and "Vertex Tweaking." If you are aligning the sphere for the very first time, or if it is really out of alignment, then start with the Projector Alignment. If you are just tweaking the alignment, then start with Vertex Tweaking.

The first step in Projector Alignment uses the "Red Ball." To turn the Red Ball on or off, press "1" on the Wii remote. When you are using the red ball, you only need one projector on at a time. You can toggle the projectors on and off using the Wii remote. The "+" and "-" buttons allow you to select the projector that you are working with. The four blue lights at the bottom of the remote indicate which projector is selected. To turn a projector on or off, make sure it's the selected projector then press the "A" button. The goal when using the red ball is to have the red cover the surface of the sphere and not overshoot the sphere on any side. You also don't want to see any cyan on the sphere. You can adjust the position and size of the red ball by using the buttons on the remote. The image can be adjusted in three different modes: translation, scale, and rotation. To use translation mode use the joystick on the nunchuk. In translation mode, the joystick can be used to move the image left, right, up and down. To use the scale mode, hold the "Z" button while using the joystick. In scale mode, up on the joystick makes the image taller, down on the joystick makes the image squatter, right on the joystick makes the image wider, and left on the joystick makes the image thinner. To use the rotation mode, hold the "C" button while using the joystick. In rotation mode, the joystick can be used to rotate the image as necessary.

When using the red ball, don't stay in one place. It is important to make sure that the image is evenly positioned on the sphere, so you will have to walk around to see both sides of the sphere. You want everything to be as uniform as possible. Sometimes it is helpful to make the red ball small so that you can center it on the sphere. Once it is centered, then you can expand it until it covers the quadrant of the sphere that you are looking at. The red ball alignment is just the first pass at aligning the sphere, so it doesn't have to be absolutely perfect.

Alignment Mode



	Translate X Translate the X coordinates of the currently selected projector.
B	Toggle Vertex Tweak Toggle between vertex tweak mode and projector adjustment mode.
	Rotate Rotate the currently selected projector.
Z	Scale Y Scale the currently selected projector vertically.
	Previous Projector Select the previous projector in the list.
A	Turn Projector On/Off Toggle whether the currently-selected projector is on.
1	Toggle Redball Toggle the redball alignment mode.
+	Next Projector Select the next projector in the list.
	Rotate Rotate the currently selected projector.
Z	Scale X Scale the currently selected projector horizontally.
	Translate Y Translate the Y coordinates of the currently selected projector.
+	Vertex Selection Select a vertex to transform when tweaking vertexes.

Once you are satisfied with the red ball alignment it is probably a good idea to press “Save alignment.” All of the changes that you make to the projectors are only saved when you press “Save alignment.” If you make changes that you don’t want to keep, pressing “Load last saved alignment” will load in the settings from the last time that you pressed “Save alignment.” It doesn’t hurt to press “Save alignment” several times throughout the alignment process to make sure that all of your adjustments are saved every step of the way.

The next step in Projector Alignment utilizes the Red Grid. From the “Display” drop down menu select “Red Grid (coarse).” Once the red grid is on the sphere, the goal is to have the grid line up between the projectors so that it looks like one seamless image. You can again turn the projectors on and off by pressing “A”. You will want all of the projectors on most of the time when working with the Red Grid. Adjust the image just as you did with the Red Ball, working to create a seamless image. You don’t have to get the lines absolutely perfect in Projector Alignment because you will do the fine tuning with Vertex Tweaking.

Once the image is fairly close to being seamless, turn on Vertex Tweaking by pressing “B” on the Wii remote. The selected projector should display a grid with the numbers 1-9 on the sphere. Use the D-pad on the remote to move around the grid. When you have a number selected, you can use the joystick to stretch the image up, down, left and right. The image will only stretch near the selected number, so if a whole side needs to move left, then you need to stretch it at the top, middle and bottom. It is sometimes confusing as to which line is being projected from which projector, so it is helpful to toggle the adjacent projectors on and off to differentiate between the lines. Also, if two lines are separated that shouldn’t be, it is good to move each of them half way and have them meet in the middle rather than moving one line all the way to the other.

Once all of the lines meet in the grid, press “Save alignment.” To perfect your alignment, you can load “Red Grid (fine)” from the Display drop down menu, which has higher resolution and thinner lines. You will probably have to make some additional adjustments when you put the high resolution grid up. Follow the same steps as when “Red Grid (coarse)” was used. When you are satisfied with your alignment, press “Save Alignment” for a final time and then press “Stop Alignment” to return the remote to Play Mode.

You will only want to use the “Reset to factory defaults” button if you physically move your projectors or if the alignment is really off. You will lose all of your current settings if you press “Reset to factory defaults,” so make sure you are careful to only press it when you mean to.

Projector alignment can be a tricky process and is best learned in a hands-on manner. Be patient and remember to walk around the sphere a lot to make sure that you can see everything as you are making adjustments. You will be rewarded for all of your effort because a well aligned sphere looks great!

Session 2

Operation and System Administration

This section is intended for System's Administrators and others that have responsibility for maintaining the hardware and software components of the Science On a Sphere system (SOS).

Overview

SOS is a collection of hardware that integrates computers and video projectors to display animated images onto the surface of a large sphere. Taken in pieces, the system consists of a sphere situated in a room, surrounded by four video projectors. Each video projector is connected and driven by a display computer. Each computer/projector pair is responsible for it's own quadrant of the sphere (four video projectors, four computers). There is an additional computer to control them all. Each display computer pulls in content, usually some type of planetary content, renders it to an Earth projection, subsets it, and upon command displays it onto the sphere. The projectors are numbered one through four. Each display computer is named for the projector that it controls with a naming convention something like (sitename1, sitename2, etc). A fifth computer is introduced to control all of the systems. The fifth computer is the network controller for the SOS computing cluster (it's name is usually sitename-nc and is usually referred to as simply "nc"). The "nc" computer is responsible for many things, namely among them: running the main user interface to the system, synchronization of the display nodes, NFS file sharing for content, real time data collection, the router/gateway to the SOS system, and providing the interface to the automation control protocol. All of the computers are Linux based (currently Redhat 4 and Redhat 5). Most sites buy a "hot" spare that is used in the case of a single computer failure. All of the software that drives and controls the SOS system is written and maintained by NOAA.

System Specifications

Each node in the SOS system is a standard computer system with mid to high-end graphics hardware. The system is generally specified so that each of the nodes are identical from a hardware perspective to allow easy swapping of components (in case of system failures).

Projectors are usually specified so that they work well in high duty hour environments. Mostly, projectors classified as "board room" projectors meet this requirement. These projectors typically have multiple fans to provide adequate cooling during the day. The projectors are also specified so that they produce a high light output (LUMENS), mostly in the range of 3500 to 5000 LUMENS.

Network

The computers are connected via a gigabit network to enable high speed communication and data transport. The SOS computer cluster mostly resides in a private, non-routable network space (usually in the 10.x.x.x network range). Each computer is isolated from the network at large because of their special responsibility. The "nc" host however, usually sits on the border between the private SOS network and the sites local Intranet. NC runs a kernel based firewall package to

protect against undesirable traffic. The firewall filters are usually designed to drop every incoming connection, except secure shell access. NC sits at the border of the network to enable outside access for remote systems administration, software updates, and to pull down real time data from the NOAA servers. While the local, private SOS network is gigabit, the external connection can be whatever the local site supports in their network infrastructure.

File Serving

NC is the file server for the cluster. All the display nodes in SOS rely on “nc” to provide access to the SOS display software and data. NC is a common link between all of the nodes. When the systems boot, “nc” should be booted first and when the systems are powered down, nc should be powered down last.

Backups

No data is backed up by default. In general all of the data that comes with the system can be retrieved from NOAA, however, there are some data files that are site specific. Here are some examples of site specific data: the custom playlist data in the SOS home directory on "nc"; the alignment configuration files that are in the home directory of each display node (usually the "sos" user); any custom or local site content that was developed and installed on the system.

It is a sites responsibility to back this content up. Generally, the playlist and alignment data are a few megabytes (usually much less). However, to back up custom content can sometimes be many gigabytes.

Power Down Schedule

Generally, it is recommended that the entire SOS cluster remain powered up all of the time if you receive real time data. The projectors only need to be on during operation and should be powered down to save lamp life. If system power down is required, then it is recommended to halt the SOS software, then halt each display node (a single press of the power button starts a graceful clean shutdown), then halt "nc" (power button click).

System Maintenance

Projector alignment should be checked frequently (once a day, ideally during the normal startup for the day) to ensure that the system is aligned properly. Usually, the system only gets out of alignment when there has been some disturbance to the projectors. It is recommended to check it daily just to ensure that the system is displaying data in an optimal manor.

Projector Filters and Lamps

Projector lamps are one of the main consumables for SOS. A typical projector lamp lasts anywhere from 1500 to 3000 hours. The image quality of the system should be checked on occasion. As a projector lamps ages, it will start to dim or show discolor and then in many cases, suddenly go out. In some cases the projector will turn on a lamp warning light indicated a new lamp is needed. It's not a bad idea to have a spare lamp on hand in case of a sudden failure. In general, it is a good idea to follow the manufactures recommendations on lamp replacement. When lamps are replaced because of age, it is

also recommended to replace all of them at the same time, since the color and intensity difference between an old bulb and a new bulb will make the sphere visualization look bad.

Projector filters should be checked monthly to ensure proper airflow. At minimum, every quarter, but that depends largely on the projectors environment. Dusty areas require more frequent filter cleaning. Dirty filters reduce cooling capacity and shorten projector lamp life. This is probably the most important of the maintenance tasks to perform.

Computer Maintenance

The SOS systems are like any other computer system. In general they run and run without the need for maintenance. Redhat releases operating system patches frequently and patches that affect security should be applied as needed. If NOAA comes across an operating system patch that adversely affects system operation, we will let sites know through the SOS Forum.

User Accounts

Every process that runs under Linux must have a user id. The SOS system uses two user id's: sos and sosrt. The user id sos is used for day to day system operation and running the SOS software. The sosrt user id is run in the background by the processes that manage and transfer the real time data feeds. Administrators of Linux sometimes need access to the super user account (equivalent to the Windows "administrator" privileges). The super user account in Linux is called "root". The password is set at machine installation and can be changed locally at the site. It is generally considered safer, or at least a better practice, to not use root directly, but rather use the "sudo" command that temporarily raises a normal users privilege to root for the duration of a single command.

Session 3

Overview and Basic System Use

Most of the Science On a Sphere® software has been written so that it is easy to use. This session is meant to familiarize users with the basics of the Science On a Sphere® system.

Starting Up the System and Shutting it Off

Before the system can be used, all of the computers must be turned on. The control computer must be the first computer turned on. Make sure to turn on the rest of the computers as well (projector computers one through four, and the hot spare [optional]). The control computer will automatically log on to a preset user account. If you want to change users you will have to log out and then log in using your user name and password that has been set.

Once you are logged in, find the icon on the Desktop labeled “SOS Start” (pictured right) and double click it. This will bring up the Science On a Sphere® interface, the SOS Stream GUI, needed to run Science On a Sphere®. A control window will open as well as a terminal. You don’t need to do anything with the terminal, but don’t close it because closing that terminal will close the SOS Stream GUI as well. You can minimize/iconize the terminal window if it is a nuisance visually. If you are going to be giving a presentation, the projectors must also be turned on. Use the provided remote to turn on each of the projectors.

To shut the system off there are several options. The recommended method is to simply press the power button once on each machine. This will initiate a graceful shutdown. The control computer should be the last one shut down. The second method is to click “Actions” from the upper panel and select “Log out.” (pictured left) This will give you the choices of Log out, Shut down, or Restart. You can also type "sudo shutdown -h now" to shutdown or "sudo reboot" to reboot in a terminal. To force a sudden power off you can hold the power button for 5 seconds. This last option is to be used only as a last resort.

SOS Stream GUI

The SOS Stream GUI is what you will use to open playlists and give presentations. At the top of SOS Stream GUI you will see four menus: “SOS,” “File,” “Library,” and “Controls.” There are also buttons similar to those on a VCR that allow you to control the opened playlist.

Opening a Playlist

A generic playlist is automatically opened when the SOS Stream GUI is started. To open a saved playlist, click on the “File” menu and select “Open Playlist.” In the window that appears, select the playlist that you would like to use. All of the playlists are saved in the directory: **/home/sos/sosrc**. (**/home/sosdemo/sosrc** for some sites)

If you make changes to your playlist while it is open, it will not automatically reflect those changes. You will need to reload the playlist by clicking the “Reload Current Playlist” button in the “File” menu.

Using a Playlist

Once a playlist is open, there are several options of how to use it. The first is to set the system on autorun mode. In this mode, the system will run through the playlist on an automatic timer. To turn on autorun, click "Autorun" under the "File" menu. The second is to control the playlist from the control computer. To do this you can use the buttons across the top of the window, the commands in the "Control" menu or the keyboard. The buttons across the top of the window are similar to those on a VCR. There is a timeline across the top with a slider bar to indicate the time in a dataset. You can move the slider bar around with the mouse to fast forward or fast backward the dataset. The commands in the "Control" menu provide all the same functions as the buttons across the top. The controls for the keyboard are listed the right side of the commands in the "Control" menu. The most common keyboard commands are the up and down arrows that allow you to move through the selected playlist, and the space bar which pauses and plays the datasets. The third way to control the playlist is using the remote control. The controls for the remote are explained in the image on the next page.

Using the Wii Remote


The Wii remote is a great tool for docents to use while giving live presentations. Before the remote can be used, it has to be connected to the system. In order to connect the remote, start the SOS Stream GUI and then press "1" and "2" simultaneously on the remote. After pressing "1" and "2," you should see the blue light flashing at the bottom of the remote. Once the remote is connected it will vibrate once and one blue light will be on. If you have two remotes, you must connect them at the same time. If the remote won't connect, close the SOS Stream GUI and restart it. Try connecting the remote again. The Wiimote software can be launched by double clicking the Wiimote icon on the desktop. Clicking the "Remotes" tab at the top of the window will also show you the status of your remote. It is good practice to leave your remote in the locked position on the "Remotes" page. This prevents other Wii remotes from interacting with the system. If the site does not have a charger for the Wii remote, then it is a good idea to turn the remote off between demonstrations to preserve the battery life. Use the power button in the top corner to turn it off. To turn it on, press "1" and "2."

Functions of the Remote

All of the functions most commonly used during a presentation are available through the use the remote. Once you have opened your desired playlist, use the mouse to click on the first dataset. You can then use the remote to navigate through the playlist. The "B" button will load the next dataset and the "1" button will load the previous dataset. Use the "A" button to pause and play a dataset. To step backward or forward frame by frame use the "-" or "+" buttons respectively. To fast forward or fast backward slowly hold the "+" or "-" buttons respectively. To fast forward or fast backward quickly, hold

Play Mode

	Basic (built-in, default)	Set as default	Make a copy
	Y tilt decrease (button) Hold to decrease y axis tilt.		
	Next Go to the next clip in the playlist.		
	X tilt increase (button) Hold to increase x axis tilt.		
	Step, then Fast Forward Steps when clicked, hold to fast forward.		
	Reset Tilt Reset the sphere tilt to 0, 0, 0		
	X tilt (axis) Change the x axis tilt.		
	X tilt decrease (button) Hold to decrease x axis tilt.		
	Toggle Playing Toggle between playing and paused.		
	Fast Forward Hold to fast forward.		
	Y tilt (axis) Change the y axis tilt.		
	Step, then Rewind Steps when clicked, hold to rewind.		
	Rewind Hold to rewind.		
	Z tilt (axis) Change the z axis tilt.		
	Y tilt increase (button) Hold to increase y axis tilt.		
	Previous Go to the previous clip in the playlist.		



the “B” button while pressing the “+” or “-” buttons respectively. These buttons are very responsive and one light press is all that is needed.

The Wii remote can also be used to tilt and position the image on the sphere. The left and right arrows tilt the dataset on its x-axis, the up and down arrows tilt the dataset on its y-axis. (*NOTE – the orientation of the x and y axis is not the same for all datasets*) To rotate the sphere on the z-axis, hold down the “A” and “B” button while rotating your wrist in the desired direction of rotation. If you want to reload the dataset in its original orientation, press the “Home” button.

It is also possible to edit the layout of the functions on the Wii remote using the Wiimote software. Click on the middle tab at the top of the Wiimote window labeled “Layouts.” The functions described above are the built-in layout and not editable, but you can make a copy of the built-in layout, which is editable. Once you have a layout that you like, you can set it as the default. Make sure that all presenters are aware of any changes that are made to the remote’s layout. A few notes about editing the remote layout:

- You can drag buttons and gestures from the legend onto the bindings; you can also drag the little button and gesture icons on each binding around. Drag icons back onto the legend to remove them from a binding.
- On the legend side of the page, if you go over to “Actions”, you'll see a list of all available actions. You can drag actions over to the "New Binding" area to create a new binding with that action.
- An “X” appears next to each binding. Clicking on it removes that binding.
- Not all gestures are allowed on all actions. If you can't drop a particular gesture on a particular action, it's probably the wrong type (trying to drop a joystick axis on an action that's expecting a button won't work, for example).
- If the layout you're editing is set as the default layout (click "set as default" next to the layouts dropdown), any changes you make are immediately reflected in the remote's behavior.

Organization of Data

Before you make playlists, it’s helpful to understand how the data is organized. All of the Science On a Sphere® datasets are put into one of the five main categories. These categories are:

- Astronomy
- Atmosphere
- Land
- Models and Simulations
- Oceans

There is also an “Extras” category that contains assorted clips and videos that don’t fit into the above categories. Within each category there are many datasets. While there are some datasets that could fit into multiple categories, we keep them in just one category to remove redundancy. A full list of all of the datasets available in the categories is available on the SOS website at: <http://sos.noaa.gov/datasets/>

Every category has a directory that contains a folder for each dataset in that category. The dataset folders contain all of the data and information that you need to put the dataset up on the sphere. You will see all of these directories at /shared/sos/media/ on the control computer. Each dataset folder contains (if available):

- P1, P2, P3, P4
- Texture file (if still image)
- Folder with raw images named for the size of the images
- An equatorial cylindrical equidistant video (.mp4) of the data
- Text file labeled labels.txt
- Text file labeled playlist.sos
- Color bars and other supporting images
- Media folder with thumbnails, videos, and supporting documents

A uniform naming convention has been used among the folders. Images that are projected onto the sphere are named for their size, movies that are projected onto the sphere are named for their dataset name and size, all labels are named labels.txt etc. This was done to make it easy for the user to know what is available in each folder.

Datasets that are related to one another are all grouped into one folder. Each dataset still has its own folder, but then those folders are all put into one folder. For instance, in the “atmosphere” category there is an “aerosol” folder. This “aerosol” folder contains three folders, one for each of our related aerosol datasets.

Two Types of Datasets

There are two main types of datasets, textures and time series. Textures are the simpler of the two. They consist of one still image that can be set to rotate around the sphere. A good example of a texture is Mars. In the Mars folder you will find just one image, named for its size, which is projected on the sphere. Often, the textures are available in several different resolutions. As the resolution increases, so does the loading time on the sphere. Textures can be rotated in any way using the functions either in the “Control” menu or on the remote.

The second type of dataset is a time series. An example of a time series is the Indian Ocean Tsunami; you can watch the waves propagate across the globe. There are several different ways that time series work. In its raw form a time series is a collection of images. The images are named numerically, in ascending order. All of these images are in a folder named for the size of images. These images can be used to display the dataset on the sphere, but you cannot rotate the dataset about on its axis's. To add versatility, the raw images can be converted to a MPEG4. MPEG4s are named for the dataset and the size of the movie. MPEG4s allow you to take advantage of all of the features available in the “control” menu or on the remote. This is the preferred format for showing time series. The MPEG4s and raw images can also be set to rotate while they are animating through a feature in the playlist. Some of the older datasets play using folder labeled P1, P2, P3, and P4. Each of these folders contains the images that each projector displays. This is the least preferred method of displaying datasets. None of the additional rotation features are available when using the P folders.

NOTE: Even if you make an MPEG4, it's good to keep the raw data available.

Playlist.sos

Within each dataset folder is a text file named playlist.sos. This file is used to specify how the data is displayed on the sphere. There is a fairly strict format that must be followed within the playlist.sos file. Any specifications that are made in the playlist.sos will be used in all of the playlists that include that dataset. Here are the parameters that can be included in the playlist.sos file:

include = Include a play list snippet for a data set.

list snippet must contain only a single clip. Usually included from the data directory where it resides.

name = Name show on menu (must specify)

Name or label for the playlist entry. The name is used as text for the play list item button on sos_stream_gui

rename = Over ride "name ="

This is a way to over ride the "name=" from an included play list

data = /path/to/data/directory (must specify)

For time series data, the /path needs to end in /path/P1, if opengl = 1, then it must end in a ".jpg" or some other image file name.

datadir = Deprecated keyword. Replaced by the new keyword "data ="

background = path to a single frame of data

Specifies the path to a background image (e.g. such as a topography image). Can be used in conjunction with "data=", where the "data=" specifies a time sequence of cylindrical data files that have an alpha transparency channel set (usually .png files). This gives a basic overlay capability.

fps = frames per second (30 if not specified)

How quickly the animation sequences through data frames.

pip = /path/to/embedded/image

The pip, is an image or MPEG4 file that will appear in a picture in a picture window on the sphere. The pip window appears based on the values set by the other pip control keywords. Multiple pip's may be specified

pipstyle = projector or globe or room

Projector is default, where the pip is replicated and placed with the default position in front of each projector. A pipstyle of globe places one pip on the globe, by default with a latitude and longitude of both zero. As the sphere is tilted and rotated, this pip moves with the globe. A pipstyle

of room places one pip on the globe, by default with latitude and longitude both zero. As the sphere is tilted and rotated, this pip remains stationary relative to the room, with the sphere data sliding underneath it.

`pipcoords = lat,lon`

This moves the pip from its default position. There must be no white space in the lat,lon specification. This is similar to setting `pipvertical` and `piphorizontal` values, but here the pip shape remains constant as it moves up and down. Using the `pipvertical` parameter, the sides of the pip follow lines of latitude, which distorts the true shape of the pip as it moves up and down. Both approaches can be useful.

`pipfps = pip playback speed in frames per second for mpeg pips`

The default pip fps is now read from the pipi video mpeg file. This allows one to override that internal value.

`piptimer = 10`

Length of time pip is displayed excluding fadein/fadeout (seconds)
Use a value of 0 for "duration of clip."

`pipdelay = 5`

Time delay before pip is displayed (seconds)

`pipwidth = 45`

Width in degrees of longitude

`pipheight = 45`

Height in degrees of longitude

`pipalpha = 0.8`

Opacity of pip over underlying image

`pipfadein = 1`

Length of time pip takes to fade in (seconds)

`pipfadeout = 2.5`

Length of time pip takes to fade out (seconds)

`pipvertical = -10`

Vertical position of pip center above equator (degrees)

`piphorizontal = 0`

Horizontal position of pip center east of projector subpoint (degrees)

`duration = repeat time in seconds for entire clip, including PIPs.`

The timing of pips is no unrelated to the underlying dataset. The underlying data loops, and dwells may apply to the first and last frame as it loops, but the pip timing is unaffected by that. To make the pips loop as well, set the duration to the desired repeat time, in seconds. The default duration is 24 hours.

firstdwell = number in millisecond

lastdwell = number in millisecond

firstdwell and lastdwell. Specify time in milliseconds that the animation will stop on the first and last frame.

Defaults to 0 milliseconds.

startframe = [some frame number] (default is 1 if not specified)

Trim a long animation. If specified, the animation will only display frames beginning at "startframe" and going through "endframe".

endframe = [some frame number] (default is the last frame)

Trim a long animation. If specified, the animation will only display frames beginning at "startframe" and going through "endframe". Endframe values can be absolute frame numbers, or if they are negative, the frame number is relative to the end of the animation. The endframe can also be the key value of "end" to specify the end of the animation

stopframe = some frame number

Stop animating when the animation reaches this frame number

animate = [0 | 1]

(if 0, then don't immediately start animating when item is loaded (must hit play). Otherwise, automatically animate when playlist entry loads. In auto presentation mode, always animate, even if animate = 0

skip = n (where n is the skip factor for a directory of files.

skip = 1 will skip every other file in a animation,

skip = 2 will play every third file, etc).

As skip gets bigger, total files animated over, goes down.

label = [default (displays frame filename) | /path/to/labels.txt]

No labels will show, if not specified, otherwise the label file contains on line per frame of that animation. This is usually used to specify a data/time stamp for a frame sequence. Label files are ignored for single texture clips.

labelColor = R, G, B, Alpha ("White" if not specified)

(also can use symbolic names: white, black, red, green, blue)

labelposition = [default | x,y (range from -1, -1 ~ 1, 1)]

(-0.3, -0.5 if not specified)

audio = /path/to/audio/file (no audio if not specified)

The audio file can be anything that Linux audio player "Mplayer" can decode.

Examples of

valid audio file formats are: .mp3, .wav, .ogg, or .mp4

tiltx = number of degrees of tilt in x-axis.

tiltx only works if the data specifies a cylindrical data set (either in mp4 or an image sequence)

tilty = number of degrees of tilt in y-axis.

tilty only works if the data specifies a cylindrical data set (either in mp4 or an image sequence)

tiltz = number of degrees of tilt in z-axis.

tiltz only works if the data specifies a cylindrical data set (either in mp4 or an image sequence)

zrotationenable = [0 | 1]

An SOS data set (time series data) can be rotated while the data is animating through time. Only supports animating around the z-axis (generally the axis that passes through the north and south poles).

Zrotation only works if the data specifies a cylindrical data set (either in mp4 or an image sequence)

zfps = frames per second (default 50)

Rate at which the zrotation feature animates. Only valid if zrotationenable is 1

zrotationangle = angle in degrees (.1 degrees by default)

Number of degrees of rotation for each time step during the zrotation.

Only valid if zrotationenable is 1

timer = number of seconds (180 sec if not specified)

timer is used in "auto presentation mode only".

Specfies how long to play a presentation.

script = filename

Run the specified script (or executable) when the clip is started. The script will be killed when the system plays the next clip. This provides a way of coordinating arbitrary additional activities with the clip. The script may also connect back to the SOS automation control interface to control the system with timing not otherwise achievable via the playlist keywords.

opengl = [true | 1 | 0] (Deprecated keyword)

This keyword is no longer used and this capability is figured out dynamically based on the value of "data="

slide = /path/to/slide/image

slide show image come via the 2nd port of Graphic Card to side wall projector or big screen monitor.

category = "a string identifier"

Categorization of this data, used to populate the library

keywords = comma separated list of keywords

keywords to aid in searching

publisher = a string identifier

The name of the person or organization who published this data

creator = a string identifier

The name of the person or organization who created this data

Because all of the data is stored in the same folder as the playlist.sos file, it is not necessary to include the entire path to the file. You only need to include the data name. For example, to include labels all you need to type is *label = labels.txt*.

A typical playlist.sos file will not include all of these parameters. At very minimum, "name" and "data" must be included. It is also recommended to always include keywords, publisher, creator, and category. Also, anything with a "#" in front of it is commented out and won't affect how the dataset is displayed. If the data was taken from online, it is often useful to include the web address of the data's original location.

Playlist Format

A playlist is an ordered list of datasets. It is often helpful to think of a SOS playlist as a music playlist in iTunes. Playlists can be saved and repeatedly used. Different playlists can be made for different presentations or shows. Also, docents can have their own playlists. All playlist file names have to end with the extension .sos and are stored in either /home/sos/sosrc or /home/sosdemo/sosrc depending on the user. The basic format of a playlist is a file that points to all of the playlist.sos files that are in the dataset folder. For example, here is a playlist that includes three datasets:

include = /shared/sos/media/oceans/indian_tsunami/playlist.sos

include = /shared/sos/media/astronomy/xray_sun/playlist.sos

include = /shared/sos/media/models/ipcc_temp/gfdl/playlist.sos

Each "include" is used to point to a different dataset. This example playlist includes the Indian Ocean Tsunami, the X-Ray Sun and the GFDL Temperature Change Model. All of the information about the labels, color bars and timing is saved in each of the separate playlist.sos files. The nice thing about this format is that everyone's playlists will be using the same versions of the data. However, if you do want to edit some of the options for a dataset, within only your personal playlist, you can do that. Simply include the changes in your demo playlist under the include. For example, if you want a faster

rotation rate on the sun and a longer lastdwell for the tsunami in your playlist, you can change it like this:

```
include = /shared/sos/media/oceans/indian_tsunami/playlist.sos
lastdwell = 7000
include = /shared/sos/media/astronomy/xray_sun/playlist.sos
fps = 50
include = /shared/sos/media/models/ipcc_temp/gfdl/playlist.sos
```

Making a Playlist

There are two basic ways to make a playlist. The first is to manually type the playlist in a text editor and save the file with a .sos extension in either /home/sos/sosrc or /home/sosdemo/sosrc depending on the user. For this you will need to know the path to each of the datasets on your control computer. There is also a playlist editor that you can use to make your playlist. This is a good option if you don't know where all of the files are located. The editor is a drop and drag program that lets you drop and drag datasets into your playlist and then rearrange them as you please. The playlist editor can be launched from the "Playlist Editor" icon on the Desktop, or through the SOS Stream GUI with the "Edit Playlists" option under "File."

The Playlist Editor has two main tabs at the top, "Playlists" and "Clip Library." The Playlist tab has a list of all the playlists on the left and shows the contents of a selected playlist in the main window. The Clip Library shows the data categories on the left and has all the datasets in a selected category in the main window. To create a new playlist, click "New Playlist" under the Playlists tab. Give it an appropriate name (avoid using spaces in Linux) and then double click on the name to open it in a new window. Then select the Clip Library tab and drag the desired clips into the playlist that was opened in a new window. Entire playlists can also be dragged into a new playlist. To edit a clip, select the "Edit Clip" button and make adjustments as desired.

One important note about the playlist editor is that it saves continuously, so there is no "Save" button. This means that you can view your playlist as you create it in the SOS Stream GUI. When the playlist editor is closed, a prompt appears that asks if the changes should be saved. This is the time to undo any changes that have been made.

Giving a Presentation

Presentations with Science On a Sphere® can take on several different formats. The simplest is autorun. In the autorun mode, the system displays each dataset for 3 minutes (if not specified otherwise) before moving on to the next in the playlist. This is a good option when a docent is not available to lead a presentation. If this format is used, it's nice to have supporting audio or text so that the audience knows what they are looking at. We have audio tracks available with a limited number of datasets. The available audio tracks are in the dataset folders. Side wall projectors or flat screen televisions can be linked to the Science On a Sphere® software to sync a PowerPoint presentation with a SOS demo. This can be used to display supporting information for each dataset.

The preferred way to present Science On a Sphere® is with a live presenter to lead the audience through a playlist. The presenter can either be around to answer

questions as visitors wander through or lead a structured presentation on a schedule. The length of a presentation can vary widely depending on the audience and topic. A standard presentation at the Planet Theater at NOAA in Boulder, CO is 30 – 45 minutes and includes 10 datasets on average.

Many sites give live presentations with the sphere throughout the day, and in between presentations leave the sphere on autorun. Presentations can be broad and include datasets from all of the categories, or narrowly focused on a topic such as climate change or the solar system. The type of programming is entirely up to the users.

Another aspect of the presentation that needs to be considered is if the audience will sit in one location or move about the sphere. With the rotation capabilities of most datasets, it is possible to have your audience seated on one side of the sphere and rotate all of the datasets to be ideally positioned in front of them. The second option is to have the audience walk around to different sides of the sphere, rather than rotating the data. There are pro's and con's to both options, so it's up to the users to decide which option best fits their needs.

Session 4

Presenter Training and Dataset Overview

One of the most compelling ways for audiences to view Science On a Sphere® is through a guided presentation by a docent. Well informed docents are able to point out features in the various datasets and stress a “take-home” message for audiences to grasp. It is important that docents know how to use the system and also understand the science that they are presenting.

Starting the System

The computers will typically be on all the time and logged into an “sosdemo” account. If the SOS Stream GUI is not open, do so by double clicking the “Start SOS” icon on the desktop. This will launch the SOS Stream GUI which is the interface for controlling the SOS system. Next, connect the Wii remote by pressing buttons 1 and 2 simultaneously. The lights on the bottom of the remote will flash until the remote connects. You can tell when it’s connected because it will buzz once and then one light will remain on.

The SOS Stream GUI automatically opens a playlist titled normal_demo.sos. If you want to use a different playlist, select “Open Playlist” under “File” and find the playlist that you prefer. You are now ready to start your presentation. You can use either the remote or the keyboard to control the system. (see page 11 for the functions of the remote and keyboard and page 19 for how to make your own playlist)

Presentation with Science On a Sphere

During the installation week, a NOAA trainer will give a 20 – 40 minute presentation with the sphere to demonstrate one method for using the sphere. Typically guided presentations can last anywhere from 15 – 60 minutes depending on your audience. A normal presentation will cover about 10 different datasets. The presentation can either be a broad overview of everything that is available on Science On a Sphere from astronomy to hurricanes and ocean currents, or can focus on specific topic such as climate change or a tour of the solar system.

Many museums develop several different presentations that cover topics of interest for their museum’s audience. The NOAA trainer will give a broad overview presentation just to highlight some of the most compelling datasets that come with the sphere. The trainer will also be available for questions about any of the datasets. All of the datasets have documentation online (sos.noaa.gov/datasets) that provide details of the dataset.

Dataset Overview

It is helpful for presenters to know what is available to them when they are developing their own playlists. The data is organized into five main categories: atmosphere, astronomy, land, oceans, and models and simulations. There is also an additional category of extras which includes movies and other assorted datasets. The “Library” tab in the SOS Stream GUI provides a playlist for each category and is a great way to browse all of the available datasets.

Session 5

Content Creation

Knowing how to create and add content to your Science On a Sphere® allows your site to have the latest and most up-to-date datasets. Members of the SOS users group often share the content that they create with the other SOS sites. This session is meant to familiarize users with the process of creating content.

Data Organization

As covered in the last section, each dataset has its own folder that contains all of the pieces that are needed to put the image up on the sphere. The only two pieces that you must absolutely have to use a dataset is the image or images and a playlist.sos file. All of the other pieces, such as the labels and color bars, are optional but nice to have. Every folder is stored in one of five categories. It will be helpful for your site to continue with the data organization method as you add your own data so that is easy to locate and use. In some cases, it is useful to create a category called “Proto” or “Prototype” where you can store new datasets that you are working on.


Types of Datasets

We’ve already that mentioned that there are two main types of datasets: textures and time series. Textures are a single, static image that can be set to rotate about the sphere. Texture datasets are relatively simple to make because you only have one image to work with. You can set the rotation rate of a texture by setting the frames per second (fps) setting in the playlist.sos file. Making a time series can be a little more difficult. There is no limit on the number of images that you include in a time series, except for available disk space. You can animate the time series at any rate, but 30 frames per second is the recommended speed. We try to create our data so that they look smooth and animate well at 30 fps. The frame rate is sometimes limited based on the pixel resolution of the data and the type of data. It is important to keep this in mind when creating a time series so that you make enough images to ensure that the dataset plays for a reasonable length. If you only make 30 images, then it will only take one second to loop through the dataset at 30 frames per second. The optimal playback speed is chosen based on the number of frames and the degree of change between each data frame in the sequence. To get smooth animations the changes between each frame should be small and the playback speed high. If a dataset is coarse, then it might animate better as a slower frame rate such as 10 – 15 fps.


For making time series, you should consider using a background image that you can then layer data on top of. You have to use PNG’s if you are going to do this because they allow for transparency. This provides a great way to save disk space, because you only need one background image. The images that have data are much smaller files. Here is an example of a background image and a transparent data frame that you can layer on top of one another:



Sea ice concentration image with transparent background



Background base map for the sea ice concentration data



Sea ice concentration image layered on top of background base map.

File Format

In order for the data to wrap properly around the sphere, it is imperative that you follow the specifications for the data format closely. Images in the wrong projection format will project on the sphere, but they won't look good. The images need to be plotted on an Equatorial Cylindrical Equidistant (ECE) projection. An ECE projection is commonly referred to as a simple lat/lon grid, where the image is a standard cartographic map projection that is twice as wide as it is tall (rectangular). 2048x1024 is the minimum acceptable size, though 4096x2048 is recommended to optimize the appearance of the image on the sphere. The SOS system is fairly flexible as to what file formats it can handle. It will accept most common format such as GIF, JPEG, PNG, TIF, etc. We prefer JPEG or PNG. If you want to use a background image and then layer data on top of it, then you should use PNG because it allows for transparency. It is important that the data fill the entire image space. If there are borders or extra space around the edges then seams will appear on the sphere with spots on the poles.

For texture data you just need one image. To be consistent with the organization, the texture images that you create should be named for their size. For a time series you need a sequence of images. The image file names should sort in ascending order from earliest to latest. To do this, we usually embed a frame number in the file name, with a sufficient number of leading zeros where necessary to sort correctly. When you create a time series, the images should be kept in a folder named for the images' size.

System Interactions with Data

When a dataset is projected on the sphere, you are really looking at four images that have been merged together seamlessly around the sphere. The Science On a Sphere® software splits the ECE images that you load using the SOS Stream GUI into four disk images every time you load a new dataset on to the sphere. Because all of the work is done by the software automatically, you don't need to do anything except point the system to where the data is located by creating a playlist.

Tools to Create Datasets

Because Science On a Sphere® uses common image formats, you can use many tools to create and edit datasets. Some of the common tools used are Photoshop, FinalCut Pro, ImageMagick, GIMP, etc. You can use whatever you have available and are comfortable using. A program like FinalCut Pro can be used to add transitions, special effects and other computer graphic techniques. At a higher level, tools like IDL, AWIPS, McIDAS, and other image analysis applications are typically used to create imagery from scientific datasets. As an example, we have used AWIPS (Advanced Weather Information Processing System) to create images from numerical forecast models. A graphics designer can use a 3D modeling application, such as 3D Studio, to create advanced visualizations for SOS.

Animation Options in the Playlist

You can optimize how a dataset is displayed by understanding all of the options that are available to you in the playlist.sos files. You can do much more than simply display the dataset. All of the functions available for the playlist are listed above in the

Overview and Basic System Use section. Now we will go over how to best use all of these functions available.

For a texture dataset, there are only a few options that you need to consider. When a texture dataset is initially loaded on the sphere, you can set whether you want it to rotate immediately or only after play is pressed. The function “animate” in the playlist controls this. If “animate” is not included in the playlist, then the default is for the dataset to automatically start rotating. “animate” can be set to either 0 or 1. 0 will prevent the dataset from animating until play is pressed, and 1 will cause the dataset to start rotating immediately when loaded. Another common function used with textures is the tilt options. For instance, we have our Earth textures set to load at a 23.5° tilt to resemble the Earth’s actual tilt. This is also useful if you are loading a dataset that highlights the poles, which are hard to see if there is no tilt. To set the tilt, use “tiltx,” “tilty,” and “titlz” to the number of degrees that you want each axis tilted. The tilt can be positive or negative.

For a time series, you have all of the options mentioned for the texture, plus many more. Rather than causing a dataset to rotate, “animate” causes a time series to start animating, but the functionality is the same. The default is for the dataset to start animating immediately. When a presentation is docent-led, it is often helpful to have the time series animate only after play has been pressed. This gives the docent time to provide background information about the dataset and explain what is going to happen. (In autorun mode “animate” is automatically set to 1 regardless of what is in the playlist.) Another option is to set “firstdwell,” which is an amount of time that the system lingers on the first frame before animating. The default is zero seconds. The time is listed in milliseconds, so “firstdwell = 4000” will dwell on the first frame for 4 seconds. You can also dwell on the last frame by setting “lastdwell.” When “lastdwell” is not set, the dataset loops continuously without pausing. Especially with model data, it is nice to set “lastdwell” so that the audience can get a good look at the last frame before the dataset loops again. If you want to stop the animation, you can set “stopframe” to the frame number that you want the animation to stop on.

With particularly long datasets it’s sometimes nice to show only a piece of the dataset. You can do that by setting the “startframe” and “endframe” to the frame numbers that you want to start and end on. An example using this is when we just want to show a loop of Hurricane Katrina formation and path. We use the 2005 Hurricane dataset, but set the “startframe” and “endframe” so that we only show the piece of the dataset when Hurricane Katrina was visible. The “endframe” can be a negative number, which counts back from the end. Another way to shorten a dataset is to set the “skip” option, which allows you to set a skip factor. When “skip” is set to one, it skips every other image, and when it’s set two, it skips every third image.

Another option that you have for times series is to not only have them animating, but also rotating. For example, the default for the Indian Ocean Tsunami dataset is for the base image to stay stationary while the waves propagate across the ocean. This means that only the audience standing in front of the Indian Ocean can see the waves. When “zrotationenable” is set to 1, then the dataset will rotate about its z axis while it animates. You can also use “zfps” and “zrotationangle” to set the frames per second rate for the dataset and the angle at which the dataset rotates. Make sure that you set your “zfps” at a rate that allows your audience to still grasp what they are looking at before it

rotates out of site. For especially busy animations, it could be distracting to the audience to see both the animation and the rotation.

There are also some functions in the playlist that should be specified when using auto run. Auto run mode cycles through the datasets in a playlist automatically, showing each dataset for a specific amount of time. You can specify the amount of time each dataset is shown by setting “timer” to the number of seconds desired. If this is not specified, then each dataset is shown for 180 seconds. If “timer” is specified and you are not showing the playlist in autorun mode, then “timer” will be ignored. It’s important to use “timer” when you also have accompanying audio tracks. You will want to make sure that the audio is synced with the playlist. You can set audio for each dataset by specifying the desired track with the “audio” keyword. The audio tracks must be compatible with the Linux Mplayer such as .mp3, .mp4, .wav, or .ogg. Audio tracks are available from NOAA for a limited number of datasets. They provide a good way to give your audience information when a docent is not available.

Picture in a Picture

Picture in a picture (pip) allows you display pictures (any of the previously mentioned image formats works) or videos (MPEG4 only) on top of any dataset. This feature can be used to display any image, but is commonly used to display color bars, charts and graphs, and other images that supply supplement information. Also, you can have multiple pips which can be either displayed all at once, or set to run like a slide show on the sphere. For example, there is a Mars dataset that has all of the landing sites on Mars labeled. To compliment this, pips are set to cycle through a slide show of images taken from different exploration trips to Mars. Images that you are going to use as pips can be stored in the dataset folder that they go with. When a pip is included, there are several options that you have to set.

There are three different styles for pips: projector, room, and globe. “Projector” is the default, where the pip is replicated and placed with the default position in front of each projector. A “pipstyle” of “globe” places one pip on the globe, by default with latitude and longitude both zero. As the sphere is tilted and rotated, this pip moves with the globe. This allows you to use pips as geo-referenced markers. A “pipstyle” of “room” places one pip on the globe, by default with latitude and longitude both zero. As the sphere is tilted and rotated, this pip remains stationary relative to the room, with the sphere data sliding underneath it.

The “piptimer” has to be set (in seconds) so that the system knows how long to display the pip. If the “piptimer” is set to 0, then the pip will be displayed for the duration of the dataset. You can delay the appearance of a pip by using “pipdelay,” which is in seconds. Rather than having the pips appear abruptly, you can use the “pipfadein” and “pipfadeout” to fade the pip in and out in a specified number of seconds. The time to fade in and out a pip is excluded in the total amount of time allotted in for the “piptimer.” By default, a series of pips will play through only once. You can set “duration” to a given number of seconds and the pips will loop based on the set duration.

In order for the pip to be an appropriate size for the sphere and in the proper proportions, you have to set the “pipwidth” and “pipheight.” The width and height are measured in degrees longitude, so it is helpful to know the original proportions of your pip when are determining the “pipwidth” and “pipheight.” You won’t want to make your

pip more than 90 degrees wide because the pip appears four times (once for each projector) and it will start to overlap. In addition to the pip size, you will also need to determine where you want it displayed on the sphere. If nothing is specified, then the pip will appear in the middle of each of the projector views. To adjust the position of the pip, use “pipvertical” and “piphorizontal.” Both of these are in degrees. “pipvertical” is the vertical position of the image relative to the equator, with positive degrees above the equator. Be careful as you move the pip up and down as images near the poles become warped. The horizontal position is relative to the center of the projector, with positive degrees east of the project. An alternative to using “pipvertical” and “piphorizontal” is to use “pipcoords,” which is set in degrees latitude and longitude. The benefit of using “pipcoords” is that there is no warping of the images, even near the poles.

When a pip is a mp4 file, the default playback speed is read from the movie file. If you want to control the frame rate of the pip, then use “pipfps” to set a new frame rate. The final option to set with a pip is “pipalpha,” or opacity. If not specified, the pip shows up opaque. If you don’t want your pip to completely block the underlying image you can adjust the opacity of the image from 0, which is completely transparent to 1, which is completely opaque.

Labels and Color bars

Labels and Color bars can be in the raw images or projected on top of them externally. It is recommended that you do not add the labels and color bars directly to the images that you create. By keeping them as external images, you have much more flexibility with their size and position within the playlist.sos file. If you do choose to put you labels and color bars directly on the images that you create, make sure that you make them big enough so that they are legible on the sphere and that they are far enough from the poles that they don’t get too warped.

One of the nice things about keeping the labels and color bars external is that they don’t move as you rotate a dataset. They stay in the same position relative to the projectors. Labels and color bars that are part of the image rotate with the image, which can cause trouble as you move the sphere about. Within the playlist.sos file you can set the position using “labelposition,” which is set by the x and y position as a pair of coordinates (x,y). Both x and y can vary from -1 to 1. The default position is (-0.3, -0.5). The label color can be changed with “labelcolor” which can be set to R, G, B, Alpha, (or the symbolic names: white, black, red, green, blue...). The default color for the labels is white.

The labels are a simple text file that contains one line for each image in the dataset. If you have a label for a texture, it will only be one line. If you have labels for a times series that contains 2000 images, then you need a text file that has 2000 lines. In the playlist.sos file, if *label = default*, then the image file names appear as the labels on the sphere. You can easily create your labels using any text editor. The label file is stored in the dataset folder and is named labels.txt. Typically the labels contain the date and maybe a title. Here are some examples of labels.txt files:

```

07/24/2004 06:45
07/24/2004 07:15
07/24/2004 07:45
07/24/2004 08:15
07/24/2004 08:45
07/24/2004 09:15
07/24/2004 09:45
07/24/2004 10:15
07/24/2004 10:45
07/24/2004 11:15
07/24/2004 11:45
07/24/2004 12:15

```

```

SSEC 08/31/2005 Katrina
SSEC 08/31/2005 Katrina
SSEC 08/31/2005 Katrina
SSEC 08/31/2005 Katrina
SSEC 08/31/2005 Maria Katrina
SSEC 09/01/2005 Maria
SSEC 09/01/2005 Maria
SSEC 09/01/2005 Maria
SSEC 09/01/2005 Maria
SSEC 09/01/2005 Maria
SSEC 09/01/2005 Maria
SSEC 09/01/2005 Maria

```

If you don't want to include the title in your labels file, then you can make an image of title that you can include as a pip. This allows you to choose the font and color scheme of your choosing when you make the title image. This is also a nice option because then you don't need to insert the title into every line of your labels file. Here is an example of a title that was made into an image for pip:



There is a lot of flexibility with the color bars. They are inserted into the playlist.sos file as a pip. Using this function, you can not only set the position, size and transparency, but also when the color bar appears, how long it stays visible, and how quickly it fades in and out. The color bars can be any common image format such as GIF, JPEG, PNG, TIF, etc. Color bars are generally named color_bar in order to keep all of the various images in the file separate.

Adding New Datasets

Once you have a new dataset that you want to put up on the sphere, there are just a couple of steps to follow. First you need to find a place to store the file on the control computer. If it fits into one of the five categories (astronomy, atmosphere, land, models, and oceans), then make a folder for it in that category. At very minimum the folder should contain the raw image or images and a playlist.sos file. There are scripts that you can get that can convert your raw images for a time series into a MPEG4. Make sure that the playlist.sos file is written according to the playlist format listed in the Overview and Basic System Use section. Remember that the playlist.sos file is used in all of the playlists that contain the dataset, so set it how everyone will want to use it. You can personalize it within your own playlists. If you have any other pieces such as labels or color bars or pips, those should go in the folder as well.

In the playlist.sos file, make sure to specify the category. The SOS software uses the category in the playlist.sos file as a tag to populate the library in the SOS Stream GUI. For example, every dataset that has atmosphere listed as its category in its playlist.sos file will appear in the atmosphere playlist in the library. If you forget to specify a category for a dataset, then it will be put into an uncategorized category in the library.

To view your new dataset you can either make a playlist that contains it, or you can update the library and find it the category that you specified. It is a good idea to view and tweak a dataset before using it in a demo, especially if you've added labels, color bars or pips. Make sure that everything looks good and appears when and where you want it too.

Sharing Datasets

If your site does not have the necessary tools or the expertise to create datasets, you can still get new datasets. NOAA is constantly adding new datasets to their library that are available for download from the FTP site. Collaboration with other Science On a Sphere® users is encouraged and recommended. This is a good way to get help making new datasets. Check out the list of other SOS sites [here](#). Sites are also encouraged to provide the datasets that they create to the NOAA library so that all of the other SOS sites can use them as well. A SOS users group, noaasos, has been created as a Yahoo Group. This is a place to ask questions, get advice and work with other sites. To join, please provide your email address to the NOAA SOS team in Boulder, CO.

Appendix A

Helpful Links

Science On a Sphere® Website: <http://sos.noaa.gov/>

Public FTP site: <ftp://public.sos.noaa.gov/>

Private FTP site: <ftp://ftp.sos.noaa.gov/>

Playlist Format: http://sos.noaa.gov/docs/pl_3_1_1.html

Existing Sites: http://sos.noaa.gov/news/sos_sites.html

Content Creation: http://sos.noaa.gov/docs/content_creation.html

Science On a Sphere® FAQ: <http://sos.noaa.gov/docs/faq.html>

SOS How To: <http://sos.noaa.gov/support/howto.html>

Linux Red Hat Website: <http://www.redhat.com/rhel/>

SOS Yahoo Users Group: <http://tech.groups.yahoo.com/group/noaasos/>